


General tips to the assembly and dismantling of FASTFIX – System packaging boxes

Assembly of the FASTFIX-Clips:





Insert into the groove on one side of the box, press across the corner and hit with a hammer (min.300 g) (slight clicking noise = perfect fit!)

Distance 1st clip from all outer corners approx. 8 cm

Unit of lenght	Clip number
(mm)	(pcs.)
150-250	1
251-600	2-3
601-900	3-4
901-1200	4-5
1201-1500	5-6
1501-2000	6-7
2001-2500	7-8

Clip distance approx. 20 to 35 cm Please always note the information on the quantity and division of the clips in the item description on the delivery note!

Dismantling / how to open a FASTFIX-Box



The clip can be taken off easy with a screwdriver. Just put it into the bending ups of the clip and with a rotation the clip is levered from the groove.

Recommended strapping

To increase transport safety. we recommend strapping over the crate clip with plastic tape



ATTENTION – BOXES WITH REQUIREMTENT IPPC !

It's only allowed to obstruct treated and marked massive wood after IPPC-Standard ISPM No. 15 to use for the protection and fixing of the transport good. The use of different, not accordingly treated wood of every kind and forms leads to the invalidity of our IPPC marking!

You can find a detailed product video on our website - or just follow the QR-Code!

